

TOP CREM

WOOD NOURISHING CREAM



GENERAL DESCRIPTION

TOP CREM is an oils and solvents based emulsion formulated for wood polishing.

TOP CREM removes traces of finger prints and dirt and leaves a glossy film that protects wooden surfaces.

DIRECTION FOR USE

Apply **TOP CREM** on a cloth or directly on the surface and polish until gloss appears on the surface.

For varnished or treated wood surfaces use the product MIKY.

TECHNICAL DATA

Appearance	ivory dense liquid
pH	8.5 ± 0.2
Density	0.958 g/ml
Active contents	30%
Viscosity	900-1000 cps

WARNINGS

Not used on spirit-treated furniture with shellac.

Labelling



Danger

May be fatal if swallowed and enters airways. Causes serious eye irritation.
Harmful to aquatic life with long lasting effects. Repeated exposure may cause skin dryness or cracking.

Read carefully the safety data sheet before use