

DIAMANT SUELO

2 COMPONENTS CRISTALLIZING POWDER FOR MARBLE SURFACES



GENERAL DESCRIPTION

The two components mixed at the point of use make a product that hardens very rapidly and polish the marble surfaces. **DIAMANT SUELO I** is a blend of metal oxides. **DIAMANT SUELO II** is a blend of salts that act as catalysts to speed up the polishing action. It is used for floors or for small surfaces like tables, lavabos, etc.

DIRECTION FOR USE

For floors in good condition that require only to get the gloss, apply 50 g of **DIAMANT SUELO I** and 50 g of **DIAMANT SUELO II** each m². The two components can be pre-mixed or shed on the floor. Use a single disc machine or a scrubber-dryer equipped with a red pad. Wet the blend of the two components just to make a cream and work that mixture for 1-2 minutes each m² until it becomes almost dry like a paste.

Rinse well and dry with a vacuum cleaner or with the scrubber-dryer. For floors in bad conditions with scratches or very porous grind with the single disc machine equipped with diamond DID pad n° 1 and n° 2. At the end of the operation once the floor is dried use a Bonnet pad to absorb the residues of a powder. For small surfaces rub with soft pad.

Maintenance

Wash with TOC or with the floor wax emulsion KEMICERA diluted at 5-10%. If necessary, buff with a floor buffing machine.

TECHNICAL DATA

| | BLEND | DIAMANT SUELO I | DIAMANT SUELO II |
|---------------------|--------------|-----------------|------------------------|
| Appearance | Ivory powder | Ivory powder | White powder |
| pH at 0.5% in water | 3.7 ± 0.2 | 2.1 ± 0.2 | 5.0 ± 0.2 |
| Active matter | 100% | 100% | 100% |
| Specific gravity | 1.25 g/ml | 0.960 g/ml | 1.53 g/cm ³ |

WARNINGS

DIAMANT SUELO I

DANGER



Harmful if swallowed. Causes serious eye damage. Toxic to aquatic life with long lasting effects.

The product is subject to ADR regulations: **UN 3077 Class 9 GI III.**

DIAMANT SUELO II

WARNING



Harmful if swallowed or in contact with skin. Causes serious eye irritation.

Read carefully the safety data sheet before use.



KEMIKA Spa - Sede operativa e stabilimento
Via G. Di Vittorio 55 - 15076 Ovada (AL) ITALIA

☎ ++39 (0) 143 80494
✉ info@kemikaspa.com

☎ ++39 (0) 143 823068
🌐 www.kemikaspa.com