MAGIC SUELO BASE

BASE CRYSTALLIZER FOR MARBLE AND TERRAZZO FLOORS



GENERAL DESCRIPTION

MAGIC SUELO BASE is a light green transparent liquid product used to crystallize and close the porosity of marble and terrazzo floors. It is used to prepare the floor to the glossy finishing that is obtained by the application of MAGIC SUELO BIANCO.

DIRECTIONS FOR USE

Floor preparation

Clean the floor with a detergent or a stripper to eliminate dirt and wax residues. In case of marks and scratches or porous surfaces make a preliminary treatment with the diamond dot rubber pads (DIAMANT FLEX system) or with the diamond impregnated pads (DID pads).

After the use of DIAMANT FLEX G-800 or of the DID 1 pad, when floor is dry, start working with **MAGIC SUELO BASE**.

Application

The crystallisation takes place only on dry floors. Spray small amount of product on 5-8 m² and buff until dry with rotary machine and steel wool pad. Use, if possible, a single disc machine of 60 kilos like the NOVADISC 51 S and the steel wool pad Disco Magic. Repeat this treatment for 3-4 times. Do not excessively wet the pads, change the pads when too wet. If necessary, eliminate the residues of the steel pad with damp mopping. After this treatment apply MAGIC SUELO BIANCO to obtain the glossy finishing.

Maintenance

The floor crystallized with MAGIC SUELO BIANCO can be maintained by dust mopping and washing with TOC. If necessary, keep crystallizing with MAGIC SUELO BIANCO. For an household maintenance use KEMICERA.

TECHNICAL DATA

Appearance	light blue liquid
рН	1.5
Density	1.175 g/ml
Active contents	27%

WARNINGS

Apply only on dry floors.



Danger

Harmful if swallowed. Causes serious eye damage. Read carefully the safety data sheet before use.



KEMIKA Spa - Sede operativa e stabilimento Via G. Di Vittorio 55 - 15076 Ovada (AL) ITALIA Tel: ++39 (0) 143 80494 – Fax. ++39 (0) 143 823068 info@kemikaspa.com - www.kemikaspa.com

