

MARBLÉ

POLISH FOR THE CRISTALLIZATION OF MARBLE



GENERAL DESCRIPTION

MARBLÉ' is a dispersion of crystallizing and polishing oxides for marble surfaces.

Restores gloss of marble floors, table tops, etc.

Excellent results are obtained on floors prepared with the DIAMANT FLEX system or with the Diamond impregnated pads DID.

DIRECTIONS FOR USE

For vertical marble surfaces or tables, apply the product and buff with a small abrasive pad (white or cream).

For floors already in good condition it is possible to use the rotary machine with a white or cream pad. For floors with scratches or in porous conditions grind and polish with system Diamant Flex with the diamond dot rubber pads or diamond impregnated pads DID. Use **MARBLÉ'** after the use of the pads of grain 800 or the DID 2 pad. The machine should be as heavy as possible. Apply small quantities at a time to small areas and proceed working. If necessary, add water to the **MARBLÉ'** paste to avoid drying. Work for 1-3 minutes for each square meter. After having polished 5-10 square meters, rinse well and vacuum off. Residues or halos can be removed with the spraycleaning method using SPRAYCLEAN B.

TECHNICAL DATA

Appearance	off white thick paste
pH	2.1
Density	1.315 g/ml
Active contents	31%
Viscosity	2800 cps

Chemical composition – Reg. (EC) 648/2004

- Non ionic surfactants : conc. < 5%

The product contains surfactants with primary biodegradability at least 90% and ultimate aerobic biodegradation complying with Reg. (EC) No. 648/2004

WARNINGS

Labelling



Warning

Causes serious eye irritation.

Read carefully the safety data sheet before use.



KEMIKA Spa - Sede operativa e stabilimento
Via G. Di Vittorio 55 - 15076 Ovada (AL) ITALIA

☎ ++39 (0) 143 80494
✉ info@kemikaspa.com

☎ ++39 (0) 143 823068
🌐 www.kemikaspa.com