

SANIDART

MULTIPURPOSE FAST CLEANER DISINFECTANT

Authorization of the Italian Ministry of Health N°20454



GENERAL DESCRIPTION

SANIDART is a ready to use disinfectant cleaner for surfaces in hospitals, clinics, nursing homes, laboratories, schools, etc. The product contains Chlorohexidine and Benzalkonium Chloride in a hydroalcoholic solution for a rapid cleaning and disinfection.

DIRECTION FOR USE

Apply the product on the surface possibly with a Microfiber cloth Extraklin or with a paper. Let act for 5 minutes to obtain a bactericide action and 15 minutes for an action against fungus and viruses, according to the following norms: UNI-EN 1276; UNI-EN 13697; UNI-EN 1650; UNI-EN 14476.

Spread evenly and let dry.

MICROBIOLOGICAL PROPERTIES

SANIDART is active for gram negative and grams positive, bacteria, for Pseudomonas and Candida Albicans and for the main types of virus also the ones with envelope like the Corona virus.

SANIDART meets requirements of the following norms:

UNI-EN 1276	Bactericide activity under suspension
UNI-EN 13697	Bactericide activity on surface
UNI-EN 1650	Fungicide activity under suspension
UNI-EN 13697	Fungicide activity on surface
UNI-EN 14476	Virucidal activity

The test have been performed by the Laboratory Merieux (Chelab) – Via Fratta 25 – Resana (TV)

TECHNICAL DATA

Appearance	green water transparent liquid
pH	7.2 ± 0.3
Density	0.958 g/ml
Active contents	32%

SANIDART Chemical Composition: 100 g of SANIDART contain:

- Benzalkonium Chloride	: 0.5 g
- Chlorhexidine	: 0.2 g
- Non-ionic surfactants	: 1.5 g
- Alcohols, Perfume (Limonene), Color	: 30.1 g
- Water	: q.s. to 100 g

The product contains surfactants with primary biodegradability at least 90% and ultimate aerobic biodegradation complying with Reg. (EC) No. 648/2004.



KEMIKA Spa - Sede operativa e stabilimento
Via G. Di Vittorio 55 - 15076 Ovada (AL) ITALIA
Tel: ++39 (0) 143 80494 – Fax: ++39 (0) 143 823068
info@kemikaspa.com - www.kemikagroup.com



Labelling



Warning

Flammable liquid and vapour. Causes serious eye irritation. Harmful to aquatic life with long lasting effects.

Read carefully safety data sheet before use

The product is subject to ADR Norms: **UN 1993 Class 3 PG III**

Do not reuse the container after the first use. keep the container in a cool place.

Valid for 2 years from the date of manufacture